









Catalogue of spare parts – versus SPEED

<u>Article No.</u>	<u>Picture</u>	<u>Description</u>	<u>Price €</u>
001	 <p>The image shows a light-colored rectangular main board with a handle on top. It has a digital display and several buttons, including one labeled 'KEY'. A small black electronic key is shown below the board. A power cord is attached to the side of the board.</p>	MAIN BOARD	310,58
002	 <p>The image shows a black rectangular electronic key. A white label is attached to the front with the following text: "ATTENTION !!! REMOVE THE POWER SUPPLY BEFORE PLUG IN AND UNPLUG !!!".</p>	ELECTRONIC KEY	31,19
003	 <p>The image shows a black rectangular pump regulator. It has a power cord with a standard two-prong electrical plug. A small label is visible on the front of the device.</p>	PUMP REGULATOR	46,62

<u>Article No.</u>	<u>Picture</u>	<u>Description</u>	<u>Price €</u>
004		PUMP for air hockey 8ft PUMP for air hockey 5ft, 6ft	146,16 118,75
005		POWER SUPPLY	51,97
006		CASSETTE FOR COIN SELECTOR	80,00
007		FRONT PLATE FOR COIN SELECTOR	11,44




<u>Article No.</u>	<u>Picture</u>	<u>Description</u>	<u>Price €</u>
008	 A green printed circuit board (PCB) with three seven-segment displays. The top display is a 4-digit display, and the two side displays are 2-digit displays. Various electronic components and traces are visible on the board.	AH SCORE DISPLAY	54,06
009	 A cylindrical metal electromagnet with a blue coil inside. It has two electrical leads: one red and one black, both with gold-colored terminals.	ELECTROMAGNET	11,44
010	 A black, circular speaker with a central cone and a surround. It has two mounting tabs on the sides and a small terminal on the bottom.	SPEAKER	8,22
011	 A push button switch with a white plastic top and a red plastic base. It has two metal terminals extending from the bottom.	PUSH BUTTON SWITCH	3,12
012	 A small, rectangular credit display with a red background and the word "CREDIT" in white. It is connected to a white ribbon cable.	CREDIT DISPLAY	23,92

<u>Article No.</u>	<u>Picture</u>	<u>Description</u>	<u>Price €</u>
013		START BUTTON	8,11
014		DOOR (without coin selector, optical sensor, motor and cables)	83,16
015		COMPLETE DOOR (incl. optical sensor, motor and cables, without coin selector)	132,53
016		MOTOR	24,95

<u>Article No.</u>	<u>Picture</u>	<u>Description</u>	<u>Price €</u>
017		OPTICAL SENSOR	24,95
018		DOOR LOCK WITH WIRE (1 pc)	16,63
019		COIN BOX RED incl. keys	45,74
020		YELLOW LEG WITH LEG LEVELLER (Article no. 021)	22,87

<u>Article No.</u>	<u>Picture</u>	<u>Description</u>	<u>Price €</u>
021		RED LEG LEVELLER WITH SCREW	3,54
022		STANDARD MALLET, BLUE	4,90
023		QUALITY MALLET, BLACK Features: metal core, rubber ring , high quality felt disc	16,80
024		RUBBER RING FOR QUALITY MALLET	3,99

<u>Article No.</u>	<u>Picture</u>	<u>Description</u>	<u>Price €</u>
025		FELT FOR BLUE HAMMER (Standard)	0,47
026		FELT FOR QUALITY MALLET, black	0,79
027		PLASTIC PUCK 70 MM, blue	7,20
028		SAFETY NET, red Made in Germany	39,00

<u>Article No.</u>	<u>Picture</u>	<u>Description</u>	<u>Price €</u>
029		RINGS FOR NET, 4 pcs	1,29
030		ADVERTISING SIGN For your individual promotion (convertable)	27,05
031		CLEANING SPRAY FOR PLAYING SURFACE	14,00